



# PeakTech 6180

SCPI Protocol

# Table of Contents

|                                                              |    |
|--------------------------------------------------------------|----|
| 1. Introduction to the SCPI Language .....                   | 1  |
| 1.1. Communication Interfaces .....                          | 1  |
| 1.2. Command Syntax.....                                     | 1  |
| 1.3. Symbol Description .....                                | 1  |
| 1.4. Programmed Parameter Type .....                         | 2  |
| 1.5. Command Abbreviation .....                              | 2  |
| 1.6. Available Command for Different Model .....             | 2  |
| 2. Common Commands.....                                      | 3  |
| 3. Select working mode.....                                  | 6  |
| 4. Set output voltage .....                                  | 7  |
| 5. Set output current.....                                   | 8  |
| 6. Output Switch Control.....                                | 9  |
| 7. Set programmable output value .....                       | 9  |
| 8. Protection switch control .....                           | 10 |
| 9. Set Timer Range.....                                      | 10 |
| 10. Set Timer loop mode.....                                 | 11 |
| 11. Fixed Output (only for single channel power supply)..... | 11 |
| 12. Query Commands .....                                     | 11 |
| 13. Application Examples .....                               | 12 |
| E.g. : Switch working mode and set the parameters.....       | 12 |
| Appendix.....                                                | 13 |

# 1.Introduction to the SCPI Language

## 1.1. Communication Interfaces

Computers communicate with the PeakTech power supply by sending and receiving commands over USB or RS232 interface. Command is sent and identified in the form of ASCII character strings for users to easily control the power supply and do user-defined development. Operations that you can do with a computer and a power supply include: Set the power supply and output voltage or current from the power supply.

Connection: Please connect the USB Device port at the rear panel of the power supply with the corresponding USB interface on the computer using an USB cable, or connect the RS232 port at the rear panel of the power supply with the corresponding RS232 interface on the computer using an RS232 cable.

## 1.2. Command Syntax

The command systems of PeakTech present a hierarchy structure (tree system) and each command consists of a "Root" keyword and one or multiple sub-keywords. The keywords are separated by ":" and are followed by the parameter settings available, "?" is added at the end of the command string to indicate query and the command and parameter are separated by "space".

For example,

```
:VOLT:OUT:IDN1 <value>
```

```
:MEASure:POWer:CHANnel1?
```

VOLT is the root keyword of the command, OUT and IDN1 are the second-level and third-level keywords respectively, all the keywords are separated by ":". <value> denotes the parameter that users can set, the default unit of the numerical parameters are listed in Appendix; "?" denotes query; the command :VOLT:OUT:IDN1 and parameter are separated by "space". All the command strings begin with ":" or "\*" and have no terminator.

## 1.3. Symbol Description

Following symbols are usually used to assist to explain the parameters contained in a command.

a) Braces { }

The options enclosed in a { } are parameters available in the command. Only one option could be selected every time, and all the options are separated by "|". For example, {ON|OFF} indicates that ON or OFF can be selected.

b) Triangle Brackets < >

The parameter enclosed in < > must be replaced by an effective value.

For example,

:VOLT:OUT:IDN1 <value>

wherein, <value> must be a numerical value, such as:

:VOLT:OUT:IDN1 20

### 1.4. Programmed Parameter Type

The commands contain 5 kinds of parameters, different parameters have different setting methods.

#### a) Boolean Parameters

The parameters could be "OFF" or "ON" ("0" or "1"), for example,

:FIXed:SWITCh {ON|OFF}

"OFF" denotes turn off switch of fixed output. "On" denotes turn on the switch of fixed output.

#### b) Consecutive Real Number Parameters

The parameters could be any value within the effective range and with the required precision, for example,

VOLT{<voltage>}

For sine wave, <voltage> could be any real number between 0.000Vpp and 30.00Vpp.

### 1.5. Command Abbreviation

Abbreviation is allowed. But if abbreviation is used, all the capital letters specified in commands must be written completely. For example,

:OUTPut:FIXed {3.3V|5.0V} also can be:

:OUTP:FIX {3.3V|5.0V}

### 1.6. Available Command for Different Model

#### a) PeakTech 6180

Fixed output setting is only available for single channel power supply.

#### b) PeakTech 4125

The corresponding commands of fixed output setting are invalid.

## 2. Common Commands

### \*CLS

Clear all the event registers in the register set and clear the error queue.

### \*ESE

Set enable register for the standard event register set.

Parameter

| Name    | Type    | Range    | Default Value |
|---------|---------|----------|---------------|
| <value> | Integer | 0 to 255 | 0             |

#### Explanation

The bit 1 and bit 6 of the standard event register are not used and are always treated as 0, therefore, the range of <value> are the decimal numbers corresponding to the binary numbers ranging from 00000000 (0 in decimal) to 11111111 (255 in decimal) and of which the bit 1 and bit 6 are 0.

Definitions of the Bits in ESE Register:

| Bit          | weights | Name | Enable               |
|--------------|---------|------|----------------------|
| 7            | 128     | PON  | Power On             |
| 6 (Not used) | 64      | URQ  | User Request         |
| 5            | 32      | CME  | Command Error        |
| 4            | 16      | EXE  | Execution Error      |
| 3            | 8       | DDE  | Dev. Dependent Error |
| 2            | 4       | QYE  | Query Error          |
| 1 (Not used) | 2       | RQL  | Request Control      |
| 0            | 1       | OPC  | Operation Complete   |

#### Return Format

The query returns an integer which equals to the sum of the weights of all the bits that have already been set in the register. For example, the query returns "144" if bit 4 (16 in decimal) and 7 (128 in decimal) are enabled.

#### Example

The command below enables bit 4 (16 in decimal) of the enable register.

\*ESE 16

The query below returns "16".

\*ESE?

\*ESE?

Query which bit in ESE register is enabled.

Example

The command below enables bit 4 (16 in decimal) of the enable register.

\*ESE 16

The query below returns "16".

\*ESE?

\*ESR?

Description

Query the event register for the standard event register set.

Parameter

| Name    | Type    | Range    | Default Value |
|---------|---------|----------|---------------|
| <value> | Integer | 0 to 255 | 0             |

Explanation

The bit 1 and bit 6 of the standard event register are not used and are always treated as 0, therefore, the query returns the decimal numbers corresponding to the binary numbers ranging from 00000000 (0 in decimal) to 11111111 (255 in decimal) and of which the bit 1 and bit 6 are 0.

Definitions of the Bits in ESE Register:

| Bit          | weights | Name | Enable               |
|--------------|---------|------|----------------------|
| 7            | 128     | PON  | Power On             |
| 6 (Not used) | 64      | URQ  | User Request         |
| 5            | 32      | CME  | Command Error        |
| 4            | 16      | EXE  | Execution Error      |
| 3            | 8       | DDE  | Dev. Dependent Error |
| 2            | 4       | QYE  | Query Error          |
| 1 (Not used) | 2       | RQL  | Request Control      |
| 0            | 1       | OPC  | Operation Complete   |

Return Format

The query returns an integer which equals to the sum of the weights of all the bits that have already been set in the register. For example, the query returns "144" if bit 4 (16 in decimal) and 7 (128 in decimal) are enabled.

Example

The query below returns "24" (bit 3 and bit 4 have already been set).

\*ESR?

### \*IDN

Return the ID character string of the instrument.

#### Description

The query returns the ID character string of the instrument.

#### Return Format

PeakTech,<model>,<serial number>,X.XX.XX

<model>: the model number of the instrument.

<serial number>: the serial number of the instrument.

X.XX.XX: the software version of the instrument.

#### Example

PeakTech, P6180,1247048,v3.0.2

### \*OPC

Set the "Operation Complete" bit in the standard event register to 1 after the current operation is finished.

### \*OPC?

Query whether the current operation is finished.

#### Explanation

Note the difference between the \*OPC? and \*OPC commands: the latter sets the "Operation Complete" bit (bit 0) in the standard event register to 1 after the current operation is finished.

#### Return Format

The query returns "1" if the current operation is finished, otherwise returns "0".

### \*RST

Restore the instrument to its default value.

### \*SRE

Set enable register for the state byte register set.

#### Parameter

| Name    | Type    | Range    | Default Value |
|---------|---------|----------|---------------|
| <value> | Integer | 0 to 255 | 0             |

#### Explanation

The bit 0 and bit 1 of the state byte register are not used and are always treated as 0, therefore, the range of <value> are the decimal numbers corresponding to the binary numbers ranging from 00000000 (0 in decimal) to 11111111 (255 in decimal) and of which the bit 0 and bit 1 are 0.

Definitions of the Bits in SRE:

| Bit          | Weights | Name | Enable               |
|--------------|---------|------|----------------------|
| 7            | 128     | OPER | Operation Status Reg |
| 6            | 64      | ---  | Not used             |
| 5            | 32      | ESB  | Event Status Bit     |
| 4            | 16      | MAV  | Message Available    |
| 3            | 8       | ---  | Not used             |
| 2            | 4       | MSG  | Message              |
| 1 (Not used) | 2       | USR  | User                 |
| 0 (Not used) | 1       | TRG  | Trigger              |

Return Format

The query returns an integer which equals to the sum of the weights of all the bits that have already been set in the register. For example, the query returns "144" if bit 4 (16 in decimal) and 7 (128 in decimal) are enabled.

Example

The command below enables bit 4 (16 in decimal) of the enable register.

\*SRE 16

The query below returns "16".

\*SRE?

\*STB?

Query the condition register for the state byte register set.

\*TST?

Perform self-test and return the test result.

If the returned bit is "0", the corresponding item of the instrument passed this test, while "1" indicates a failure.

\*WAI

Wait for the finish of the operation.

## 3. Select working mode

- [SENS]:FUNC:PLATform {COMMon|PROGram}  
COMMON :Switch to Common mode  
PROGram :Switch to Programming mode



2. [SENS]:FUNC:MODE {IND|PAR|SER|DUAL}  
IND :Switch to Independent mode  
PAR :Switch to Parallel mode  
SER :Switch to Serial mode  
DUAL :Switch to Dual-supply mode

## 4. Set output voltage

1. [SENS]:VOLT:OUT:{IND1|IND2|PAR|SER|PDU|NDU} <value>  
IND1 <value> :  
Set output voltage for channel 1 under independent mode <0.000—30.00>  
  
IND2 <value> :  
Set output voltage for channel 2 under independent mode <0.000—30.00>  
  
PAR <value> :  
Set output voltage for Parallel mode <0.000—30.00>  
  
SER <value> :  
Set output voltage for Serial mode <0.000—60.00>  
  
PDU <value> :  
Set output voltage for positive supply under Dual-supply mode <0.000—30.00>  
  
NDU <value> :  
Set output voltage for negative supply under dual-supply mode <0.000—30.00>
2. [SENS]:VOLT:OVP:{IND1|IND2|PAR|SER|PDU|NDU} <value>  
IND1 <value> :  
Set protective voltage for channel 1 under Independent mode<0.100 - 31.50>  
  
IND2 <value> :  
Set protective voltage for channel 2 under Independent mode<0.100 - 31.50>  
  
PAR <value> :  
Set protective voltage for Parallel mode <0.100 - 31.50>  
  
SER <value> :  
Set protective voltage for Serial mode <0.100 - 63.00>  
  
PDU <value> :  
Set protective voltage for positive supply under Dual-supply mode <0.100 - 31.50>

NDUA <value> :

Set protective voltage for negative supply under Dual-supply mode <0.100 - 31.50>

## 5. Set output current

1. [SENS]:CURR:OUT:{IND1|IND2|PAR|SER|PDU|NDUA} <value>

IND1 <value> :

Set output current for channel 1 under independent mode <0.020—3.000>

IND2 <value> :

Set output current for channel 2 under independent mode <0.020—3.000>

PAR <value> :

Set output current for Parallel mode <0.100—6.000>

SER <value> :

Set output current for Serial mode <0.020—3.000>

PDU <value> :

Set output current for positive supply under dual-supply mode <0.020—3.000>

NDUA <value> :

Set output current for negative supply under dual-supply mode <0.020—3.000>

2. [SENS]:CURR:OCP:{IND1|IND2|PAR|SER|PDU|NDUA} <value>

IND1 <value> :

Set protective current for channel 1 under Independent mode <0.020 - 3.150>

IND2 <value> :

Set protective current for channel 2 under Independent mode <0.020 - 3.150>

PAR <value> :

Set protective current for Parallel mode <0.020 - 6.300>

SER <value> :

Set protective current for Serial mode <0.020 - 3.150>

PDU <value> :

Set protective current for positive supply under Dual-supply mode <0.020—3.150>

NDUA <value> :

Set protective current for negative supply under Dual-supply mode <0.020—3.000>

## 6. Output Switch Control

1. [SENS]:OUTPut:{ SWITCh1|SWITCh2} {ON|OFF}  
ON: Enable output switch status  
OFF: Disable output switch status
2. [SENS]:PROTect:{VOLTage|CURRent};{IND1|IND2|PAR|SER|PDUA|NDUA};SWITCh {ON|OFF}  
ON: Enable voltage or current Protective Switch  
OFF: Disable voltage or current Protective Switch

## 7. Set programmable output value

1. [SENS]:PVOLT:OVP:{IND1|IND2|PAR|SER|PDUA|NDUA} <value>  
IND1 <value> :  
Set programmable protective voltage for channel 1 under Independent mode  
<0.100-31.50>  
  
IND2 <value> :  
Set programmable protective voltage for channel 2 under Independent mode  
<0.100-31.50>  
  
PAR <value> :  
Set programmable protective voltage for Parallel mode <0.100 - 31.50>  
  
SER <value> :  
Set programmable protective voltage for Serial mode <0.100-63.00>  
  
PDUA <value> :  
Set programmable protective voltage for positive supply under Dual-supply mode  
<0.100-31.50>  
  
NDUA <value> :  
Set programmable protective voltage for negative supply under Dual-supply mode  
<0.100-31.50>

2. [SENS]:PCUR:OCP:{IND1|IND2|PAR|SER|PDUA|NDUA} <value>  
IND1 <value> :  
Set programmable protective current for channel 1 under Independent mode <0.020 - 3.150>  
  
IND2 <value> :  
Set programmable protective current for channel 2 under Independent mode <0.020 - 3.150>  
  
PAR <value> :  
Set programmable protective current for Parallel mode <0.020 - 6.300>  
  
SER <value> :  
Set programmable protective current for Serial mode <0.020 - 3.150>  
  
PDUA <value> :  
Set programmable protective current for positive supply under Dual-supply mode <0.020 - 3.150>  
  
NDUA <value> :  
Set programmable protective current for negative supply under Dual-supply mode <0.020 - 3.150>

## 8. Protection switch control

1. [SENS]:PROTect:{VOLTage|CURRent}:{IND1|IND2|PAR|SER|PDUA|NDUA}:SWITCh {ON|OFF}  
ON: Enable programmable voltage or current protection switch  
OFF: Disable programmable voltage or current protection switch

## 9. Set Timer Range

1. [SENS]:TRAN: {IND1|IND2|PAR|SER|DUAL} <value>  
:IND1 <value> :Set time range for channel 1 under Independent mode <1-99>  
:IND2 <value> :Set time range for channel 2 under Independent mode <1-99>  
:PAR <value> :Set time range Parallel mode <1-99>  
:SER <value> :Set time range Serial mode <1-99>  
:DUAL <value> :Set time range Dual-supply mode <1-99>

## 10. Set Timer loop mode

1. [SENS]:ROUN: {IND1|IND2|PAR|SER|DUAL} {SEQU|LOOP}  
:IND1 {SEQU|LOOP} :  
Set the loop mode for channel 1 under independent mode  
  
:IND2 {SEQU|LOOP} :  
Set the loop mode for channel 2 under independent mode  
  
:PAR {SEQU|LOOP} :  
Set the loop mode for Parallel mode  
  
:SER {SEQU|LOOP} :  
Set the loop mode for Serial mode  
  
:DUAL {SEQU|LOOP} :  
Set the loop mode for Dual-supply mode

## 11. Fixed Output

**(only for single channel power supply)**

1. [SENS]:OUTPut:FIXed {3.3V|5.0V}  
:3.3v :Output fixed 3.3V  
:5.0v :Output fixed 5.0V
2. [SENS]:FIXed:SWITch {ON|OFF}  
ON: Enable Fixed output switch  
OFF: Disable Fixed output switch

## 12. Query Commands

[SENS]:MEASure:{POWEr|VOLTage|CURRent}:{CHANnel1|CHANnel2}?  
:POWEr  
:CHANnel1? : Query for the output power of channel 1  
:CHANnel2? : Query for the output power of channel 2  
:VOLTage

:CHANnel1? : Query for the voltage of channel 1  
:CHANnel2? : Query for the voltage of channel 2  
:CURRent  
:CHANnel1? : Query for the current of channel 1  
:CHANnel2? : Query for the current of channel 2

## 13. Application Examples

### E.g. : Switch working mode and set the parameters

**Target:** Common mode, switch to Parallel mode, output 20V ,4A

| Step | SCPI Command         | Comment                                         |
|------|----------------------|-------------------------------------------------|
| 0    | *IDN?                | /*Query ID to check the operating state*/       |
| 1    | :FUNC:PLAT COMMOn    | /*Switch to Common mode*/                       |
| 2    | :FUNC:MODE PAR       | /*Switch to Parallel mode*/                     |
| 3    | :VOLT:OUT:PAR 20.000 | /*Set output voltage for Parallel mode to 20V*/ |
| 4    | :CURR:OUT:PAR 4.000  | /*Set output current for Parallel mode to 4A*/  |
| 5    | :OUTPut:SWITCh1 ON   | /*Enable output switch status*/                 |

**Note:** Step 3 and 4 do not require the fixed order; you can adjust based on your operating habits.

# Appendix

## Default unit of numerical parameters

| Parameter | Default unit |
|-----------|--------------|
| Voltage   | V            |
| Current   | A            |